identifier for the hook which was tested.

- (2) Loads shall be applied to the throat of the hook since loading the point overstresses and bends or springs the hook.
- (3) Hooks shall be inspected periodically to see that they have not been bent by overloading. Bent or sprung hooks shall not be used.

[47 FR 16986, Apr. 20, 1982, as amended at 51 FR 34562, Sept. 29, 1986]

§ 1915.114 Chain falls and pull-lifts.

The provisions of this section shall apply to ship repairing, shipbuilding and shipbreaking.

- (a) Chain falls and pull-lifts shall be clearly marked to show the capacity and the capacity shall not be exceeded.
- (b) Chain falls shall be regularly inspected to ensure that they are safe, particular attention being given to the lift chain, pinion, sheaves and hooks for distortion and wear. Pull-lifts shall be regularly inspected to ensure that they are safe, particular attention being given to the ratchet, pawl, chain and hooks for distortion and wear.
- (c) Straps, shackles, and the beam or overhead structure to which a chain fall or pull-lift is secured shall be of adequate strength to support the weight of load plus gear. The upper hook shall be moused or otherwise secured against coming free of its support.
- (d) Scaffolding shall not be used as a point of attachment for lifting devices such as tackles, chain falls, and pull-lifts unless the scaffolding is specifically designed for that purpose.

§ 1915.115 Hoisting and hauling equipment.

The provisions of this section shall apply to ship repairing, shipbuilding and shipbreaking.

(a) Derrick and crane certification. (1) Derricks and cranes which are part of, or regularly placed aboard barges, other vessels, or on wingwalls of floating drydocks, and are used to transfer materials or equipment from or to a vessel or drydock, shall be tested and certificated in accordance with the standards provided in part 1919 of this title by persons accredited for the purpose

- (b) The moving parts of hoisting and hauling equipment shall be guarded.
- (c) Mobile crawler or truck cranes used on a vessel. (1) The maximum manufacturer's rated safe working loads for the various working radii of the boom and the maximum and minimum radii at which the boom may be safely used with and without outriggers shall be conspicuously posted near the controls and shall be visible to the operator. A radius indicator shall be provided.
- (2) The posted safe working loads of mobile crawler or truck cranes under the conditions of use shall not be exceeded.
- (d) Accessible areas within the swing radius of the outermost part of the body of a revolving derrick or crane, whether permanently or temporarily mounted, shall be guarded in such a manner as to prevent an employee from being in such a position as to be struck by the crane or caught between the crane and fixed parts of the vessel or of the crane itself.
- (e) Marine railways. (1) The cradle or carriage on the marine railway shall be positively blocked or secured when in the hauled position to prevent it from being accidentally released.

[47 FR 16986, Apr. 20, 1982, as amended at 67 FR 44543, July 3, 2002]

§1915.116 Use of gear.

- (a) The provisions of this section shall apply to ship repairing, shipbuilding and shipbreaking except that paragraphs (c) and (d) of this section shall apply to ship repairing and shipbuilding only.
- (b) Loads shall be safely rigged before being hoisted.
- (c) Plates shall be handled on and off hulls by means of shackles whenever possible. Clips or pads of ample size shall be welded to the plate to receive the shackle pins when there are no holes in the plate. When it is not possible to make holes in or to weld pads to the plate, alligator tongs, grab clamps or screw clamps may be used. In such cases special precautions shall be taken to keep employees from under such lifts.
- (d) Tag lines shall be provided on loads likely to swing or to need guidance.

§ 1915.117

- (e) When slings are secured to eyebolts, the slings shall be so arranged, using spreaders if necessary, that the pull is within 20 degrees of the axis of the bolt.
- (f) Slings shall be padded by means of wood blocks or other suitable material where they pass over sharpe edges or corners of loads so as to prevent cutting or kinking.
- (g) Skips shall be rigged to be handled by not less than 3 legged bridles, and all legs shall always be used. When open end skips are used, means shall be taken to prevent the contents from falling.
- (h) Loose ends of idle legs of slings in use shall be hung on the hook.
- (i) Employees shall not be permitted to ride the hook or the load.
- (j) Loads (tools, equipment or other materials) shall not be swung or suspended over the heads of employees.
- (k) Pieces of equipment or structure susceptible to falling or dislodgement shall be secured or removed as early as possible.
- (1) An individual who is familiar with the signal code in use shall be assigned to act as a signalman when the hoist operator cannot see the load being handled. Communications shall be made by means of clear and distinct visual or auditory signals except that verbal signals shall not be permitted.
- (m) Pallets, when used, shall be of such material and contruction and so maintained as to safely support and carry the loads being handled on them.
- (n) A section of hatch through which materials or equipment are being raised, lowered, moved, or otherwise shifted manually or by a crane, winch, hoist, or derrick, shall be completely opened. The beam or pontoon left in place adjacent to an opening shall be sufficiently lashed, locked or otherwise secured to prevent it from moving so that it cannot be displaced by accident.
- (0) Hatches shall not be open or closed while employees are in the square of the hatch below.

- (p) Before loads or empty lifting gear are raised, lowered, or swung, clear and sufficient advance warning shall be given to employees in the vincinity of such operations.
- (q) At no time shall an employee be permitted to place himself in a hazardous position between a swinging load and a fixed object.

 $[47~{\rm FR}~16986,~{\rm Apr.}~20,~1982,~{\rm as~amended~at}~67~{\rm FR}~44543,~{\rm July}~3,~2002]$

§ 1915.117 Qualifications of operators.

Paragraphs (a) and (d) of this section shall apply to ship repairing and shipbuilding only. Paragraphs (b) and (c) of this section shall apply to ship repairing, shipbuilding and shipbreaking.

- (a) When ship's gear is used to hoist materials aboard, a competent person shall determine that the gear is properly rigged, that it is in safe condition, and that it will not be overloaded by the size and weight of the lift.
- (b) Only those employees who understand the signs, notices, and operating instructions, and are familiar with the signal code in use, shall be permitted to operate a crane, winch, or other power operated hoisting apparatus.
- (c) No employee known to have defective uncorrected eyesight or hearing, or to be suffering from heart disease, epilepsy, or similar ailments which may suddenly incapacitate him, shall be permitted to operate a crane, winch or other power operated hoisting apparatus.
- (d) No minor under eighteen (18) years of age shall be employed in occupations involving the operation of any power-driven hoisting apparatus or assisting in such operations by work such as hooking on, loading slings, rigging gear, etc.

§1915.118 Tables.

The provisions of this section apply to ship repairing, shipbuilding and shipbreaking.

TABLE E-1—DIMENSIONS AND SPACING OF WOOD INDEPENDENT-POLE SCAFFOLD MEMBERS

Structural members	Light duty (Up to 25 pounds per square foot)—Height in feet			Heavy duty (25 to 75 pounds per square foot)—Height in feet		
	≤24	>24≤40	>40≤60	≤24	>24≤40	>40≤60
Poles or uprights (in inches) Bearers (in inches)	2x4 2x6	3x4 or 2x6 2x6	4x4 2x6	3x4 2x8	4x4 2x8	4x6 2x10